



Multi-functional Camera

User's Guide v15.1

1. Be sure to read this guide before using the device.
2. Please keep this instruction in a safe place for future reference.

Instructions v15.1



Note:

1. The device will automatically enter the video or recording or motion detection status, please pay attention to the indicator changing when using.
2. Video:sound and image recording at same time;
Rec: only sound recording;
M-Rec: Motion detection recording.
- 3.Be sure to insert a valid TF(Micro SD) card before using.

A. Product parameters

- 1) image sensor: high-definition CMOS sensor;
- 2) visual Angle: about 72 degrees;
- 3) minimum illumination: 10Lux or above.
- 4) battery capacity: about 2000mah.
- 5) duration: about 20 hours.
- 6) storage temperature: -10 ~ 70 degrees.
- 7) speed: ~ 30 frames.

- 8) memory card type: Micro SD card.
- 9) memory card capacity: support 4GB-32GB(recommended use above 4GB storage card)
- 10) video resolution: 640*480.
- 12) adaptive interface: USB2.0, USB1.1.
- 13) support system: XP/Vista32/WIN7 and above, Mac OS.
- 14) battery full time: 8~10 hours (with 5V/1A charging head standard)
- 15) working humidity: 15~85%RH9.

B.Product Operation Guide

Power On/Off:

On: long press "power" key two seconds, red, blue light at the same time, can be turned on.

Off: long press "power" key two seconds when the device is power on, that is to realize shutdown.

If there is no shutdown or dead, you can reset it to realize shutdown.

1. Charging

This rechargeable lithium battery, when it is low power, please charge it first, the device can be charged by 5V1A USB charger or mobile power.

Note: 1).when charging, red and blue light flashes, full of power, red and blue light.

2).The battery is large, and you can charge it for about 8~10 hours.

2. File reading

Connect the device to the computer by the usb cable, open the corresponding disk, find the file, and play it.

3. Video Recording

To Record:slip the mode key to the "Video" position and power on. The red and blue light is on, then the red light goes out three times and the device enters the video mode.

To Save: during the recording, press the "Power", the red light is on, the device saves the data and turn to the standby mode. If you press the "Power" key for two seconds during recording, the red light flashes three times, the device saves the video and power off.

4.Sound Recording

To Record: slip the mode key to the "Rec" position and power on. The red and blue light is on, then the blue light goes out three times and the device enters the sound recording mode.

To Save: during the recording, press the "Power" key,the red light is on, the device saves the data and turn to the standby mode. If you press the "Power" key for two seconds during recording, the red light flashes three times, the device saves the video and power off.

5. Motion Detection Recording

To Record: slip the mode key to "M-Rec" position and power on. Red and blue light, then blue light, red light flashes, Once it detects any moving object within the range, the indicator lights out; The device will record for 2 minutes and save the recording footage, and detect if there is any moving object. Yes, the video will continue to be recorded.No,it will continue to detect.

To Save: during the recording, press the "Power" key,the red light is on, the device saves the data and turn to the standby mode. If you press the "Power" key for two seconds during recording, the red light flashes three times, the device saves the video and power off.

6. Reset

When the device is not working properly due to illegal operation or other reasons, it is necessary to reset the product. Press the button in the reset hole with fine material.

7. Record While Charging

While the device is off, connect the device to a power source via the USB cable provided. And then turn the device on to start recording.

8. Time Setting

The device will automatically generate the time file TAG.TXT on the card when used.

After shutdown, the device is connected to the computer, and the tag.txt file is opened, and the time is modified and saved. The format is: 2017-10-01 23:59:59. Remove the device from the computer, restart it, and the time will burn into the device.

C.Indicator Description

Indicator status description		
Work status	Indicator status	Note
Video	The red light flashes three times and goes off	
Rec	The blue light flashes three times and goes off	
M-Rec	Blue light on, red light flashes	
Charge	Red, blue light flash at same time	Full: Red, blue light stays on

D.Disclaimer

1.The usage of this device is subject to the relevant national laws and regulations, DO NOT use this product for any illegal activities.

2.DO NOT point the camera lens to the direct sun light or permanent damage may occur.

Keep away from fire. Never expose the device to any fire source.

3.DO NOT disassemble and modify. Doing so causes the risk of electric shock, burn injury and other health related hazard.

4.DO NOT let water, liquids, or foreign matter get inside the device. Extra precaution is advised where it is raining, snowing, near the ocean or other form of water. In case any of the symptoms are present, turn off the device immediately and contact us for further support.

5.DO NOT drop the device or permanent damage may occur.