



Function

1. **Reset:** Restore factory settings
2. **Display Ratio:** adjust the screen ratio of 4:3 or 16:9
3. **Sleep:** auto power-off
4. **Blue screen :** Blue screen or black screen control
5. **Sharpness:** Image resolution debugging
6. **Mode:** SYS3

Product Safety Tips:

Please carefully read all the documentation that is included in the product packaging, before you use this device. To prevent fire or shock hazard, do not expose the monitor to rain or moisture. When the power fails, do not attempt to repair by yourself. Please contact a professional technical service person or dealer.

Before using this device, make sure that all cables are properly connected and the power cord is not damaged. If there is any damage, please contact your dealer immediately.

Do not block vents on the cabinet, do not place the product on or near the upper radiator or direct heat.

This device should use only the type of power source indicated on the label. If you don't know the type of power supply, contact your dealer or local power company.

Use appropriate power adapter for your local power standard.

Do not overload in the circuit, overload may result in fire or electrical shock.

In case of thunderstorm weather or when not in use for a long time, should unplug the power cord of this device.

This can prevent damage to the display due to power surges.

Do not place any object into or allow any liquid spilled into the vents on the display cabinet.

To ensure the normal operation, the display should only be used with UL listed PC, properly configured power adapter and labeled with 12V DC.

If you experience any technical problems during using this device, please contact a professional technical service person or dealer.

Please ensure that the insulation, anti-static during the installation, avoid burning out the board and LCD screen.

User Manual



Function parameter

Screen dimensions: 7inch
 Resolution: 1280×800
 System: PAL/NTSC (Video)
 Input Power: 12V
 Consumption: 6W
 Input Signal: VGA, HDMI, 2Video



1. Power
2. Menu
3. Function up
4. Function down
5. Mode
6. Video 2
7. ACC+



1. DC 12V
2. HDMI
3. VGA
4. Video 1



Function Keys

1. Power on/off
2. Video Select
3. Function down
4. Function up
5. Menu
6. Mode select



Color

1. **Brightness:** adjust the screen brightness.
2. **Contrast:** adjust the screen contrast.
3. **HUE:** adjust the screen color
4. **Color temp:**
5. **Exit**



1. **Language:** including English, French, German, Spanish, Italian, Dutch, Russian, Traditional-Chinese, Simplified-Chinese, and Japanese.
2. **H position:** adjust the screen horizontal position.
3. **V position:** adjust the screen vertical position.
4. **OSD Timeout:** menu close time.
5. **Transparent:** menu display or transparent.
6. **Exit**